


INSTALLATION GUIDE

CLASH

TRIWATT DUOCOLOR



<p>1. Open front ring counterclockwise.</p>	<p>2. Unscrew and open diffuser, unplug the connector.</p>	<p>3. Select wattage and color by dip switch.</p>
<p>4. Drill the hole for cable, install the Waterproof cable protector.</p>	<p>5. Fix the light to ceiling/wall protector.</p>	<p>6. Wiring.</p>
<p>7. Plug the connector, close diffuser.</p>	<p>8. Close front ring clockwise.</p>	<p>9. Turn on power.</p>

Total Power	10.5W	10.5W	14W	14W	19W	19W
Lamp Power	9.13W	9.13W	12.18W	12.18W	16.53W	16.53W
Colour Temp.	3000K	4000K	3000K	4000K	3000K	4000K
Lumen Output	1300lm	1400lm	1680lm	1800lm	2200lm	2400lm
Efficacy	125lm/w	135lm/w	120lm/w	130lm/w	115lm/w	125lm/w



Note! Please follow these instructions carefully and keep it for future reference. This luminaire must be installed by a licensed electrician. Make sure the power is disconnected before performing installation or maintenance.



NB! Vennligst følg denne bruksanvisningen nøye og oppbevar den for fremtidig referanse. Denne armaturen skal kun installeres av en autorisert elektriker. Sørg for at strømmen er frakoblet før du skal utføre installasjon eller vedlikehold.

Color	Color temperature	Power	Lumen	CRI/RA	Beam angle	El-nr.
White	3000/4000K	10.5/14/19W	1300/1400/1680/1800/2200/2400lm	80	110°	32 046 82
Black	3000/4000K	10.5/14/19W	1300/1400/1680/1800/2200/2400lm	80	110°	32 046 83

